



## **Safety Notice:**

- $\ensuremath{\textcircled{1}}$  Electrial installation should be done by registered electrician.
- ② Disconnect the luminaire from supply and until luminaire is cooled down,before replacement of the driver.
- ③ Never touch the lamp while luminaire is switched on.
- ④ In any case of malfunction disconnect luminaire from supply immediately, don't try to repair the luminaire yourself, repair should only be done by registered electrican or offcial service agent.











